

READ, FOLLOW AND SAVE THESE INSTRUCTIONS

MODEL #GL42588

INDOOR 12 LED CORK LIGHT

INSTRUCTIONS

Indoor Usage only

Item is not waterproof or weather proof.

Remove battery tab from the battery door.

Unfold the fairy light and insert it into an empty bottle
(**DO NOT** insert into bottles filled with liquid).

Use ON-OFF switch to turn the lighted cork on and off.



TO REPLACE THE BATTERIES

Use a screwdriver (included in the box) to remove the screw and open the battery door.

Replace the 3 X LR44 batteries.

Close the battery door.

Replace the screw.

IMPORTANT INFORMATION: Battery should be recycled as per local guidelines.

CAUTION

- This is not a toy. For decorative use only.
- **Replace batteries ensuring proper polarity.** Failure to insert batteries in the correct polarity, as indicated, may shorten the battery life or cause them to leak.
- **Do not mix old and new batteries.** Replace all batteries of a set at the same time.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium or nickel-metal hydride) batteries.
- Remove batteries if exhausted or if product is to be left unused for a long period of time.
- Do not dispose of batteries in fire.
- Keep batteries away from children. If swallowed, a battery could cause serious injury or death in a short period of time. Seek medical attention immediately.
- Batteries should be recycled or disposed of as per manufacturer's recommendations.
- Batteries should be recycled or disposed of in a safe manner.